

MT181

GWR loco brake shoes and hangers

For driving wheels over 5'2" diameter

Use 0.7mm wire for mounting pivots, to secure the blocks to the hangers, and for lower cross-rods. The pivot wire is also used to align the layers when laminating them. To adjust the sit of the brakes in relation to the wheels, we suggest that you mount the brake shoes tight to the wheel rim, then 'tweak' the top pivots with fine snipe-nosed pliers to obtain an accurate alignment with sufficient clearance to avoid electrical problems.



Top left: Castle, Star and Saint
4-6-0s

Bottom left: Original Hall 4-6-0; 4300
and 5300 2-6-0s; 3100 and 4100
2-6-2Ts

Top right: Modified Hall, Grange and
Manor 4-6-0s; 6300 2-6-0; 6100 2-6-2T

Bottom right: King 4-6-0

The shoes may suit more GWR classes
than those listed.

**Mainly Trains is part of
Wizard Models Limited**

**PO Box 70, Barton upon Humber
DN18 5XY**

**Tel 01652 635885
web www.wizardmodels.ltd,
e-mail info@wizardmodels.ltd**

© Wizard Models Limited 2025